

## Craft ROBO (CC200 & CC100)

### *What is a Carrier Sheet?*

The purpose of the carrier sheet is to carry medias without backing and undersized medias through the Craft ROBO. The sticky/tacky surface of a carrier sheet holds down media during the cutting process keeping it in place and prevents the machine from jamming the media. Carrier sheet should be covered when it is not in use. Fibrous medias are not recommended for use with carrier sheet as some fibers may remain on the surface—reducing the life and effectiveness of the carrier sheet.

sticky/tacky hold down area

